

Product Guide

User and Maintenance Information

Important Information:
Keep instructions for future use.
Read all instructions before assembly and use of product.

CUSTOMER SERVICE:

United States

PO Box 2

Ulster Park, NY 12487

Office hours: 9-5 EST

Phone (800) 777-4244

Fax (800) 336-5948

(845) 572-3468

www.CommunityPlaythings.com

Sales@CommunityPlaythings.com

United Kingdom

Robertsbridge

E. Sussex TN32 5DR

Phone 0800 387 457

Fax +44 (0)1304 843 731

www.CommunityPlaythings.co.uk

Sales@CommunityPlaythings.co.uk



H86 Apron

Recommended Use

The H86 apron helps prevent the soiling of children's clothes when playing with water or painting.

Cleaning

Engage hook and loop before washing. Wash in warm water and air dry. After washing remove lint from velcro. Do not iron.

Construction

The apron is made out of waterproof urethane coated nylon with velcro fasteners.

User Modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

Ordering Parts

To order replacement parts, contact your Customer Center with a description of the part(s) needed and the ID Code from the product.

Use only replacement parts supplied by Community Playthings.

