

# Push me-pull me



## Recommended Use

Recommended for children between the ages of 2 to 3.

### **⚠ WARNING**

▲ This product is intended for use by children of immature judgement therefore supervision is required at all times.

### **⚠ CAUTION**

▲ For indoor use only, this product is not waterproof.

## Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

## Cleaning

Wipe the wood parts with a damp cloth and a mild detergent. Do not use excessive water.

## Construction

The wooden components are manufactured from solid birch protected with a child-safe finish. The large wheels are made with soft plastic tires, and the industrial casters with non-marking wheels.


## User modifications

We cannot be responsible for modifications made by customers to our products in the field, without our supervision, testing or evaluation.

## Ordering Parts

To order replacement parts, contact Customer Service with a description of the part(s) needed and the serial number of the product.

**Use only replacement parts supplied by Community Playthings.**



## IMPORTANT

**Retain these instructions for future reference.**

© 1993 by Community Products (UK) Ltd  
BU80 Eu 0199 Revision 00

## Community Playthings

Brightling Road, Robertsbridge, TN32 5DR UK  
Phone: 0800 387 457 Fax: +44 (0)1304 843 731  
[www.communityplaythings.co.uk](http://www.communityplaythings.co.uk) [sales@communityplaythings.co.uk](mailto:sales@communityplaythings.co.uk)