

# Product Guide

## User and Maintenance Information

### IMPORTANT INFORMATION:

Keep instructions for future use. Read all instructions before assembly and use of product.

#### CUSTOMER CENTERS:

##### United States

PO Box 2  
Ulster Park, NY 12487  
Office hours: 9-5 EST  
Phone (800) 777-4244  
Fax (800) 336-5948  
(845) 572-3468

www.CommunityPlaythings.com  
Sales@CommunityPlaythings.com


##### United Kingdom

Robertsbridge  
E. Sussex TN32 5DR  
Phone 0800 387 457  
Fax +44 (0)1304 843 731  
www.CommunityPlaythings.co.uk  
Sales@CommunityPlaythings.co.uk

## A35 Tote Box

### Recommended Use

Tote Boxes fill a need for storage, organization, and portability. On the shelf, a tote holds materials and supplies, or a particular child's belongings. Children and teachers can carry the tote to an activity area where the contents are needed. Totes help the clean-up process, too. When not in use, stacking saves space.



### WARNING

- ▲ This product is intended for use by children of immature judgment, therefore supervision is required at all times.

### Maintenance

Periodically inspect for cracks, breaks, loose parts, missing parts, and/or malfunctions. Remove the product from service when any condition develops that might make operation unsafe.

### Cleaning

The tote can be washed with soap or mild detergent, and water. Disinfectants can be used. Do not use abrasive cleaners or cleaning solutions containing pine oil (such as Lysol) for cleaning the plastic pan.

### Construction

Totes are made from sturdy polypropylene.

### User Modifications

We cannot be responsible for modifications made by customers to our products in the field without our supervision, testing, or evaluation.

### Ordering Parts

To order replacement parts, contact your Customer Center with a description of the part(s) needed and the ID Code from the product.

**Use only replacement parts supplied by Community Playthings.**

